

Rapid Response Cone

> Assembly Guide

Rapid Response Cone
S0015000

The SYR Rapid Response Cone is the super speedy all-in-one cost effective solution for emergency spillages!

Our tall mobile safety cone with mop holders gets to the point of the spillage fast. Simply grab it and go for safer floors.

All components are stored inside the cone itself, please carefully remove all packaging in preparation for assembly.



- ① Clip in both HD handle holding clips at the top of the cone
- ② Push holding tray in to the side of the cone
- ③ Turn cone upside down and click in small clips to the inside to hold the holding trays in place. The small clips should be facing you when pushing in
- ④ Insert fully 3 x 2" castors and 1 x 2" braked castor into the 4 base holes
- ⑤ Turn cone back to the upright position on the castors, then place top handle into the hole at the top
- ⑥ Secure top handle with the round clip by placing through the hole and then clicking into place

