



SMART, POWERFUL CLEANING



Features

Replacement parts are readily available and straightforward to replace, making the maintenance of your Nomad effortless.

If your part is not listed, or if you have any queries about Nomad, just call our office and ask for a Nomad Technical Team member - they will be happy to assist.

S0443000 | Vacuum Hose S0418000 | Water Filter S0411000 | Rubber Coupling S0402000 | Power Battery

S0419000 | Vacuum Filter S0430209 | Brush O-Ring S0402000 | Water Cap Key S0403000 | Battery Charger 42V 3A