


# Sponge Scourer No Grip

AN EVERYDAY  
ESSENTIAL



## Features

Used to scour, usually used to clean cookware. For general cleaning of floors, walls and most surfaces.  
15cm x 9.5cm.

970327 | No grip

### > Shift Tough Dirt

Abrasive scourer effectively removes stubborn dirt and particles from hard surfaces.

### > Excellent absorbency

The porous fibres of the sponge make them excellent at absorbing water or other liquid solutions.